

BEN'S COUNTRY WOODSHOP BLANKET CHEST


Cutting & Drilling




Cut 2 of these side panels.




Cut the front and back panel.



Cut one bottom panel 28 1/2" long & 17" wide.



Cut the top back piece.



Cut the top cover.


For step-by-step instructions and many photos of this project, visit:

<http://www.start-with-free-woodworking-plans.com/blanket-chest-plans.html>.


Sign up for our ezine so you won't miss any of our new pocket hole woodworking plans.

BEN'S COUNTRY WOODSHOP BLANKET CHEST PLAN

Assembly



Join the bottom piece to the 2 side pieces.



Join the two sides and the bottom to the front.



Flip your 4 pieces over and add the back piece.



Now you can add the 2" hinge strip to the top of your blanket chest.



Connect the hinges to the top cover and your blanket chest is fully assembled.



Your blanket chest is ready for finishing!